



# Non-Adhesive Privacy Filter Installation Instructions



**Wait!**

**We strongly recommend watching an installation video before attempting to install your privacy filter. Scan the QR code with your phone or tablet or visit**

**[www.photodon.com/installation-videos](http://www.photodon.com/installation-videos).**

## **Verify the filter size:**

1. Hold the filter up to your device to verify it is the proper size. If it is not the intended size, send an email to [sales@photodon.com](mailto:sales@photodon.com). Please attach a photo if possible.

## **Clean:**

2. With your device turned off, use the provided cleaner/wipe and the microfiber cloth to clean the screen.

## **Remove the filter liners(s):**

3. Carefully remove the front and back liners from the privacy filter. Some non-adhesive filters may come with one or both liners removed. If one or both sides of your filter do not have a small, rectangular sticker in one corner, that side does not have a liner. Non-adhesive filters have a matte and a glossy side. Either side will provide . The matte side will provide privacy black out and some anti-glare, the glossy side will provide maximum privacy black out. Using the provided cleaner/wipe, clean the side that will be facing in (attached to the screen).

## **Apply adhesive strips to the privacy filter:**

4. The double-sided adhesive strips are between a blue liner and a clear liner sheet. Remove one of the strips, holding on to the blue liner. This will expose the adhesive. Place the strip adhesive side down along the edge of the back side of the filter (the side you cleaned in step 3.). Use a finger or the provided squeegee to seal the adhesive strip to the filter and remove any bubbles that may appear under the adhesive. Continue applying the strips around the edge of the filter. The strips do not need to be touching; gaps between them will not affect installation. You may not need all of the strips. 2 sets of strips is enough for most devices. TV's and other large screens may need up to 4 sets of strips.

5. Remove the blue liner from the adhesive strips, leaving the adhesive behind on the filter. You may want to save the blue liners to cover the adhesive if you need to remove the filter.

## **Install the privacy filter:**

6. Rest the filter on the bottom bezel with the adhesive strips on the monitor side. Align the filter left to right. When you are satisfied with the alignment, tip the filter towards the device screen and gently press along the adhesive attachment points to hold the filter in place. If the alignment seems off, the privacy filter can be removed and realigned.

7. Run your finger along the edge of the filter to remove and bubbles that may be present in the adhesive.

8. Clean the front of the filter with the provided cleaner/wipe and microfiber cloth.

9. Power on the device to check the filter. The privacy filter will darken the screen slightly. Consider adjusting the brightness of the screen if necessary. If the image seems blurry, verify that the filter is tight against the screen.

If you have installation issues or questions, contact us at 847-377-1185, email [sales@photodon.com](mailto:sales@photodon.com) or live chat at [www.photodon.com](http://www.photodon.com).

Reviews and comments on ways to improve our products, services, and customer experience are appreciated!  
Contact us or leave a testimonial at [www.photodon.com/testimonials](http://www.photodon.com/testimonials).