



Standard Screen Protector Installation

Before installing the protector:

1. Install the **test film** to evaluate the effects of the film.
 - a. Clean the device screen.
 - b. Using the protruding tab, gently pull back the bottom liner about 1" to expose adhesive backing.
 - c. Allow the film to touch the screen, and then remove the bottom liner.
 - d. Push any bubbles out with the included squeegee, and then remove the top liner.
2. If satisfied with the effects:
 - a. Carefully unpackage the protector.
 - b. Hold the protector up to the screen to see if it is the correct size.

NOTE: There should be a .5-1mm gap around the edges for ease of installation.

3. Ensure the installation area is clean and free from dust.
4. Before removing the liners, wipe the protector and clean the device thoroughly with the cleaning supplies provided.
5. Installing the screen protector:
 - a. Using the protruding tab, gently pull back the bottom liner 1-2" to expose the adhesive backing.
 - b. Center the protector on the device and allow the adhesive backing to contact the screen.
 - c. Slowly pull back the bottom liner.

NOTE: If the alignment seems off, pull up the protector and start over. Ensure no dust attracted itself to the screen.

NOTE: Small air bubbles can be worked out later. If the alignment is good, continue with the installation.
 - d. While pulling off the bottom liner with one hand, use the squeegee in the other hand to push out air and help the protector contact the screen. When the liner is completely removed, discard it.
 - e. If there are no bubbles or specks on the screen, use the squeegee to seal the edges of the protector.
 - f. Remove the top liner and discard.
 - g. If there are bubbles or specks, see the installation tips on the back of this page.

For helpful installation videos, visit www.photodon.com/videos.

Installation Tips:

- If there are bubbles after the installation, push them out to the nearest edge with the squeegee.
- Small bubbles that are not able to be worked out may dissipate in a day or two.
- Bubbles that have specks in the middle are typically dust, which will not dissipate.
 - To remove dust particles and finish the installation:
 - Locate the white tacky tape included with the kit and expose the sticky side.
 - Lift the corner of the protector closest to the dust particle.
 - Lightly press the tacky tape onto the particle to remove it (usually the particle is on the protector itself).
 - Once removed, ensure no dust is on the exposed screen. Use the cloth to remove any dust on the screen.
 - Allow the protector to slowly re-adhere to the screen, using the squeegee to help it seal again.
 - When satisfied with the installation, remove the top liner.
- For larger protectors, it may help to use a marker to circle where the dust particle is on the liner.
- For detailed instructions go to <https://www.photodon.com/Screen-Protector-Installation-Instructions.pdf>.

If you have installation issues or questions on anything else, contact us at 847-377-1185, email sales@photodon.com, or live chat with us at Photodon.com.

Reviews and comments on ways to improve our products, services, and customer experience are much appreciated!

Contact us or you can leave a testimonial at here:

www.photodon.com/kudos.html