

# Adhesive Privacy Filter Installation Instructions

## *In The Package:*

**One** Privacy Filter

**One** piece of double-sided tape

**One** 1 oz. bottle of cleaning solution

**Two** microfiber cloths

## *To ensure a successful installation:*

### **AVOID BUBBLES:**

- Install filter to a clean, dust-free screen in a clean environment.
- Avoid wearing linty clothes when applying the filter.
- Turn power off to improve detection of particles/bubbles.

This filter allows straight on viewing of the screen while limiting its visibility from side angles.

1. Before beginning, hold the filter up to your monitor to verify that you have received the proper size.
2. Next, thoroughly clean the screen. Wipe down monitor with a clean cloth to remove dust or dirt.
3. Use the tacky tape to gently remove any remaining lint or dust from the screen (or use a vacuum with a clean brush attachment to remove any remaining dust from the screen and surrounding area).

**DO NOT RUSH THIS STEP.** Dust that remains between the filter and the screen prevents the filter from laying smoothly and creates bubbles.

4. Remove the top liner.
5. Wipe front and back of filter with screen cloth if lint or dust is visible.
6. Use the tab to peel back a small portion of the back liner. Be careful not to expose too much tacky backing at a time to limit dust attraction.

**IMPORTANT!** After you have removed the protective liner, DO NOT TOUCH the filter's adhesive backing as fingerprints can transfer and remain on the filter.

7. With a couple of inches of backing removed, align one edge and center the filter on the screen. Allow the filter to contact the screen when correctly positioned.
8. Apply light pressure to top side of filter to seal. If you observe an air bubble, lift the filter to the bubble and apply light pressure on the top side to remove. If the air bubble has a dot in the center, this is lint or dirt (use enclosed tacky tape to remove).
9. Slowly pull a small amount of backing at a time. Allow the filter to lay in place without putting tension on the filter.
10. As you near the end, remove the back liner completely and allow the filter to slowly lay in place. Apply light pressure around the edges to seal.

***The installation is now complete!***

## ***Additional Note:***

This filter will slightly darken the screen. Consider adjusting the screen brightness after application.

***Photodon also offers a variety of high quality screen care products to improve your screen viewing experience.***

***Screen Protectors  
Monitor Hoods  
Screen Cleaning Products  
Business to Business Services  
Promotional Microfiber Cloths***

***We welcome your questions and suggestions about our products.***

***Find us at: [www.photodon.com](http://www.photodon.com)***

***sales@photodon.com / 847-377-1185  
Monday-Friday 9:00am-5:00pm EST***